

ScanCombifloor - Glossy concrete floors

SCANMASKIN
MACHINES-MINERALS-KNOW-HOW

Seven steps to a glossy concrete floor. This guide is for the Scan Combiflex 45 and Scan Combiflex 500i.



Step 1. SC-Blue. Grinding with this segment reveals the stone that will be visible in the glossy



Step 2. SC-Green.

Impregnate with SC-Proof.
Wait about 10 to 12 hours.



Step 3. SC-White



Step 4. RDC-Blue
(Part no. 593034)



Step 5. RDC-Red
(Part no. 593035)



Step 6. RDC-White
(Part no. 593036)



Step 7. RDC-Green
(Part no. 593038)

It is very important to carefully vacuum the floor between each grinding step.