

# ScanCombifloor - Glossy concrete floors

**SCANMASKIN**  
MACHINES-MINERALS-KNOW-HOW

Seven steps to a glossy concrete floor.  
This guide is for the Scan Combiflex 700 RC.



**Step 1. SC-Blue.**  
Grinding with this segment reveals the stone that will be visible in the glossy Combifloor.



**Step 2. SC-Green.**

**Impregnate with SC-Proof.  
Wait about 10 to 12 hours.**



**Step 3. SC-White**



**Step 4. RDC-Blue  
(Part no. 593034)**



**Step 5. RDC-Red  
(Part no. 593035)**



**Step 6. RDC-White  
(Part no. 593036)**



**Step 7. RDC-Green  
(Part no. 593038)**

**It is very important to  
carefully vacuum the floor  
between each grinding step.**

**Each set contains nine  
grinding segments.**